

---

TECHNICAL BULLETIN No. 012-2008

23-07-2008

---

**Model: SXV RXV 450-550**

**Subject: No speed display on instrument panel**

Dear dealership,

there have been a number of cases in which no speed is displayed on the instrument panel of the vehicle in question. The instrument panels returned to us after replacement proved to be in perfectly good working order. As a result, we therefore kindly ask that the following checks be performed before replacement:

- 1) Check that the speed display function has not been inadvertently disabled with the relative setting button. If in doubt, perform the procedure to enable display of all screens. The following is the procedure for enabling and disabling screens.

**To disable a screen:**

1. Start the vehicle
2. Display the screen you wish to disable
3. Press **SCROLL** until **WS** is displayed at the bottom right of the display
4. While holding the **SCROLL** button, flash the high-beam light 5 times
5. Release the **SCROLL** button

**To enable all screens:**

1. Carry out the same procedure as above, starting from the **ODO** screen

- 2) Start the vehicle, connect to Axone, display the "**Engine Parameters**" screen and check that the vehicle speed display is fixed at "2 km/h" (standard value), then rotate the front wheel vigorously and check that the speed indicated on Axone increases. If the indicated speed remains at 2 km/h, check the speed sensor connector (located under the lock barrel) for oxidation, bent pins or other faults. Check, with the ignition switch ON, for battery voltage on the blue/green and yellow/pink wires on wiring side.